

⚠ WARNING


--	--

Children have died from furniture tipover.







- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture


ELEMENTS




HARDWARE

<p>A</p>  <p>x4</p>	<p>B</p>  <p>x4</p>	<p>C</p>  <p>x4</p>
<p>D</p>  <p>x1</p>	<p>E</p>  <p>x10</p>	<p>F</p>  <p>x4</p>


STEP 1



STEP 2



STEP 3



living-elements.com.au

DISTRIBUTED BY:

Visy Retail Services Pty Ltd (AU): 1300 734 714

Visy Board Limited (NZ): 0800 443 058