





⚠ WARNING



Children have died from furniture tipover.


- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture




6 RUNNER BASKET KIT
436W X 650H X 545D MM
ASSEMBLY INSTRUCTIONS


PARTS LIST:




1 x LEFT (TOP)
SLIDING FRAME



1 x RIGHT (TOP)
SLIDING FRAME




1 x LEFT (BOTTOM)
SLIDING FRAME




1 x RIGHT (BOTTOM)
SLIDING FRAME



5 x CONNECTOR BARS




3 x WIRE BASKETS
(2 RUN)



TOOLS REQUIRED:




Wood Block



Hammer

To construct product, place a wood block over frame and tap lightly with a hammer.



HINT:

Do not try and fully fit one Connector Bar before starting the other 4 Connector Bars. To start, fit all 5 Connector Bars to frames so they just hold in place.

To finish the frame assembly, gradually work around each corner with your hammer and woodblock, gently tapping the frames and connector bars together.



INSERT BASKETS AT
DESIRED POSITIONS AS REQUIRED

flexistorage.com.au
flexistorage.co.nz

MADE IN CHINA

Distributed by:

Visy Retail Services Pty Ltd (AU): 1300 734 714

Visy Board Limited (NZ): 0800 443 058